
MAD NETWORK WIRING DIAGRAM



MATISSE DIGITAL SIGNAGE/TTG NETWORK WIRING DIAGRAM


MACHINE ROOM




MATISSE DIGITAL SIGNAGE MAIN and AUX COP WIRING DIAGRAM

MATISSE DIGITAL SIGNAGE MAIN and AUX COP WIRING DIAGRAM

MAIN COP




AUX COP



MATISSE DIGITAL SIGNAGE MAIN COP WIRING DIAGRAM


MATISSE DIGITAL SIGNAGE MAIN COP WIRING DIAGRAM

MAIN COP



TTG NETWORK WIRING DIAGRAM


TTG NETWORK WIRING DIAGRAM



TTG AND MATISSE DIGITAL SIGNAGE WIRING DIAGRAM

TTG AND MATISSE DIGITAL SIGNAGE WIRING DIAGRAM

MAIN COP




APPENDIX: MOUNTING & WIRING INSTRUCTIONS

Mounting




NOTE2: Please make sure to mount the Matisse player same as the above picture with HDMI cable facing towards the input HDMI on screen


Wiring




NOTE1: Please use the provided (CWP0000016.00) plug terminal for screen. Wire the positive terminal to the positive on the power supply and negative to the negative on power supply.



Machine Room



<u>COP</u>



Machine Room: Only Dipswitch 1 on extender should be turned



NOTE3: Please make sure Machine Room extender portion is not loose in -COP back box